







1. CLEANING THE PRE-FILTER

- 1. Unplug the Airdog.
- 2. Place your fingers in the grove on the back panel and pull towards you.
- 3. To remove the pre-filter pull towards you.
- 4. Place pre-filter on flat surface, hover/brush the dust off.







2. WASHING THE COLLECTING PLATES

- 1. Remove the collecting plates.
- 2. Place one hand underneath the collecting plates to avoid damage.
- 3. Use a soft bristle brush, warm water and a mild cleaning agent to thoroughly clean..







3. DRYING

- 1. Collecting plates must be fully dried before being reinstalled in unit.
- 2. Place collecting plates in an airy place or on top of a radiator and allow to dry for 8 to 12 hours (overnight).
- 3. When completely dry, reinstall





Surgically Clean Air always!!















