

Importato da/imported by/importé de/importado de: Gima S.p.A. - Via Marconi, 1 - 20060 Gessate (MI) Italy gima@gimaitalv.com - export@gimaitalv.com

www.gimaitalv.com Made in China

BEE 25765



Operating Instructions for Digital Clock/Timer

Please remove the insulation tag from the battery chamber to start operation

CLOCK SET

- 1. The clock has to be reset after replacing a new battery.
- 2. Press H button for desired hour and press M button for desired minute. When done, press ST/SP button.

TIMER ALARM (count down)

- 1 Press H and M button at the same time to reset the timer to zero
- 2 Press H button to set hour Press M button to set minute(s). When done, press ST/SP button to start alarm counting down.
- 3. Alarm will sound with a loud beep (lasting 60 seconds). Press key to stop the alarm.
- 4 Maximum Timer Alarm is 19 hours and 59 minutes.

STOP WATCH (count up)

- 1. Press H and M button at the same time to reset the timer to zero.
- 2. Press ST/SP button to begin counting.
- 3. While timer is counting up, press ST/SP button once to pause. Press the ST/SP button again to continue counting up.
- 4. Maximum stopwatch time is 19 hours and 59 minutes
- * Press H. M. and ST/SP button at the same time to show real time*